



# OWNER'S MANUAL

106-00163-01 ECH




如A图,在准备安装仪表板上开孔 $\Phi 52\sim 53\text{mm}$ ,并保证面板后面有至少70mm的空间。


**A** Pic A : Before installation , firstly , to open a hole (Dia:52~53mm) of the panel, make sure there is a space with (70mm backyard of panel) as well



如B图,拧开后盖,然后将仪表放入开好孔的仪表面板中  
Pic B: Twist off the cover then put the gauge in hole



如C图,将仪表调整好位置后用仪表后盖将仪表锁紧在仪表面板上  
**C** Pic C: Mount the gauge in hole, twist the back cover on after adjustment.



如D图,关于外形尺寸的标注说明  
Pic D: Size and annotations

## gps installation instructions/天线安装说明:



**GPS天线正面安装:**  
Installed in front:



最好的安装方式  
Best




一般安装方式  
General



可能收不到GPS信号  
Cann't receive GPS signals

**GPS天线反面安装**  
Installed in reverse:



GPS天线反向安装  
Reverse the GPS antenna installation

此面要求是塑胶或不能屏蔽GPS信号的材料。  
this surface material required plastic or can not shield GPS signal material

技术参数:  
工作电压: 9~32VDC,  
工作电流:  $\leq 70\text{mA}$ ;  
工作温度:  $-30\sim +75^\circ\text{C}$   
存储温度:  $-40\sim +85^\circ\text{C}$ 。

Specification:  
Operating Voltage: 9~32VDC,  
Operating current:  $\leq 60\text{mA}$ ;  
Operating temperature:  $-30\sim +75^\circ\text{C}$   
Storage temperature:  $-40\sim +85^\circ\text{C}$ 。



## 仪表功能说明:

- 按住Mode按键3秒,进入背光设置模式,让后短按按键改变背光颜色:背光顺序红色(默认)→绿→蓝→白→黄→黄绿→橙→紫→(自动)。自动:设置为自动背光时背光熄灭2秒再点亮,然后1分钟自动切换一次背光颜色。照上面顺序循环切换。
- 打开电源,仪表即可开始工作,仪表开始工作时,处于搜索信号状态,SOG会自动计数,计数到300,如果还没有搜索到GPS信号,SOG会显示E01。处于搜星状态或中途GPS信号丢失SOG会闪烁。
- 短按仪表背面的按键,可以实现KNOTS、MPH、KM/H单位的切换,并自动保存。  
名词解释: SOG: 表示对地速度-航速; COG: 表示相对于地面位置的移动方向,表示相对于正北顺时针方向的角度  
TRIP: 小计里程,掉电自动清零; ODO 累计里程,掉电数据不清零。 COG、TRIP、ODO跟根据客户要求定制。
- 故障代码: E01 表示上电时GPS搜索不到GPS信号。  
: E02 表示中途GPS信号丢失。  
: E03 表示仪表内部电路出现故障。

## Operation:

- Press the button (less than 2 seconds) to change the backlight color. ( Backlight sequence red (default) → green → blue → white → yellow → yellow green → Orange → Purple → (Automatic switch).)  
Automatic: Automatic switch: The back light will be off for about 2 seconds, then switch (red (default) → green → blue → white → yellow → yellow green → Orange → Purple), one color per minute.
- Power on, the GPS speedometer start working and seeking if any positive GPS signal available (in 300 seconds maximum). Meanwhile, the "SOG" increasing like 0, 2, 3... 299, 300. If the GPS speedometer could not receive any GPS signal during the 300 seconds, the "SOG" will show "E01"
- Users could select the speed unit via quick pressing the button of gauge's back.


## Glossary:

- SOG: Speed over ground;  
COG: Course over ground  
TRIP: Total mileage for one working time, data will be cleared when power off.  
ODO: Total mileage for all working time, data will not be cleared when power off.

Remarks: Function for COG、TRIP、ODO could be customized.

## 4、Error:

- E01 : No GPS signal available when power on  
E02 : GPS signal lost during driving/sailing  
E03 : Internal faults



## 接线:

- 红色线--+9~32VDC
- 不连接
- 橙色线--背光 (+9~32VDC)
- 蓝色线--电源负极 (-)

## Connection:

- Red --+9~32VDC
- NC
- Orange --Backlight (+)
- Blue --Ground (-)

## E

参考E图连接电线  
Pic E(Wires Connecting)