


User Guide for 85mm Multi-function GPS Speedometer and Tachometer



Gauge Bracket Dashboard Panel

Gauge Body

GPS Antenna



Wire harness definition

black	Power Ground -
red	Power+(12/24V)
blue	Left Turn (+)
pink	Hazard Alarm(+)
purple	Right Turn (+)
white	High Beam(+)
Brown	Oil Pressure Alarm(+)
green	Neutral(-)
green	Gear 1(-)
green	Gear 2(-)
green	Gear 3(-)
green	Gear 4(-)
green	Gear 5(-)
green	Gear 6(-)
yellow	Fuel Gauge signal(ohm)
orange	Engine Speed signal(pulse)
grey	External Button (+)




Fig. 1

Fig. 2

Fig. 3

Install the Gauge

- Cut an 85mm (3 3/8") hole in the panel (II) allow a clearance of . behind the panel.
- Remove fastening ring (I), insert gauge from front. Tighten gauge (III) using fastening ring (I)
- Securely fasten the GPS antenna, preferably outdoors (or inside front windscreen) so that it has a clear view of the sky to pick up satellite signals. Connect the antenna cable to socket on the gauge. Do not cut cable.
- After turning power on, allow the gauge to sample satellite signal for 1 minute.
- All data is for reference only and should not be trusted as sole navigation source.

Parameter Menu: PULSE, Unit, odo, oil

Press and hold the back button, then power on.

The LCD will keep switching & showing "PULSE, Unit, odo, oil" every 1 second.

Choose the target menu, release button to enter setting.

1. "PULSE": Set the engine speed RPM Ratio, unit: pulse/rpm, range: 0.5-655.3




How to confirm RPM Ratio?

- If your sensor is installed on the flying wheel panel, the RPM ratio is equal to the number of gears of the engine.
- If the speed signal takes from **W-Terminal of Alternator**, the RPM ratio is equal to the half of the number of poles.

Normal RPM Ratio for Reference:

OutBoard Engine		InterBoard or Gasoline Engine			Diesel Engine
Electric Poles	RPM Ratio	Cylinder	Stroke	RPM Ratio	RPM Ratio=Gear Number
4	2	4	4	2	
6	3	6	4	3	
8	4	8	4	4	
10	5	10	4	5	
12	6	12	4	6	

- If you cannot find **W-terminal of Alternator**, you will need order separately our **GR01 RPM sensor adapter** to get RPM signal, which just need cross around the ignition coil cable.



2. “odo” (Set Total Odometer)



After selecting “odo”, the LCD will show for example “5000” (5000 km) , press the button to set the flashing digit from 0 to 999999 to set the target odometer value.

3.“ Unit” (Set Unit: km/h, mph)



LCD will switch show km/h, mph .Then release button, and wait for menu to complete flashing.

3. “oiL”(Set Fuel Gauge Signal)



LCD will show“o00002” (ohm range 10~180Ω) .

Press button to set target ohm range depends on **Table A**

Release button and wait for menu to complete flashing.

Table A

o 00000	0-190Ω
o 00001	0-180Ω
o 00002	10-180Ω
o 00003	240-33Ω
o 00004	240-30Ω

5. Odometer & Trip Odometer

Power on the speedometer, and long Press to reset the Trip Odometer to Zero.



Please noted: After setting, you should disconnect both Power+ and GND, and then re-power on, then it will save the setting. If you just cut Power +, then it'll not work properly.

6.Fuel Level &Voltmeter

Power on the speedometer, and press the button shortly to switch fuel level to voltmeter.